UFLOAT & 2 PIECE FLOAT SYSTEM SETUP 4 POINT CHECK

This document outlines the setup process for using a U-Float system. Before installation on your paramotor, run through this checklist. Replace and check your co2, bobbin and quarterly.

1. ☐ **CHECK VALVE SCREW**

   The valve screw cover allows you to easily deflate an inflated bladder. Behind this screw on both sides is a small o-ring. Make sure it's seated with no marks or damage for an airtight seal. **Ensure this is securely tightened to 45in. lbs of torque or 5nm**

2. ☐ **CHECK MANUAL INFLATION CLIP**

   The manual inflation system includes a mechanically fastened clip. Clips increase the amount of force required to deploy the system and prevent accidental inflation.

3. ☐ **CHECK CO2 BOBBINS**

   At the bottom of the inflation system is a threaded bobbin container. As it's screwed on it compresses a spring against the bobbin. Make sure the yellow bobbin is inserted and tightened.

4. ☐ **INSERT CO2 CARTRIDGE**

   Screw a 33g CO2 cartridge into the left and right inflation systems, make sure they are tight.

MOUNTING

Using the velcro straps and the slide release straps, attach the inflation system to your harness straps or frame. For added security, electrical tie straps can be used to prevent velcro from coming apart.

LOCATIONS

Recommended mounting location is on your harness shoulder straps.